

Einleitung (for English see the reverse)

Die Firmware Versionen V1.0 und V1.10 weisen eine identische Schnittstelle (*.XIF) und identische Funktionalität auf. Sie unterscheiden sich in der Hardware-Kompatibilität:

- Die Version V1.0 ist für BKN-Geräte mit 3150 LON-Chip kompiliert (produziert bis 2011)
- Die Version V1.10 ist für BKN-Geräte mit FT3150 LON-Chip kompiliert (produziert ab 2012)

Firmware updaten

Achtung:

Die Firmware Version muss mit der Hardware Version (siehe Produktionsdatum auf dem Gerät) übereinstimmen.

1. Im Binding Tool (LonMaker, ALEX, NL220 ...) die Download Funktion wählen
2. Firmware Datei „uk_3_xy.apb“ (resp. „uk_3_xy.nxe“ und „uk_3_xy.xif“) auswählen
3. Firmware Download starten

File Version	Datum	Bemerkung
1.0	04.06.2012	Andreas Marty, erstellt

Overview (für Deutsch siehe Vorderseite)

The firmware versions V1.0 and V1.10 have an identical interface (*.XIF) and provide identical functionality. They differ only on the hardware compatibility:

- The Version V1.0 is compiled for BKN devices with 3150 LON chip (produced until 2011)
- The Version V1.10 is compiled for BKN devices with FT3150 LON chip (produced from 2012)

Firmware update

Attention:

The firmware version must match with the hardware version (see production date on device).

1. Select Download function in the engineering tool (LonMaker, ALEX, NL220 ...)
2. Select the firmware file „uk_3_xy.apb“ (or „uk_3_xy.nxe“ and „uk_3_xy.xif“)
3. Start the firmware download