



WARNING!

Before replacing actuator, damper must be inspected and determined to be fully functional. See NFPA 80 &/or NFPA 105 for recommended check list.

Replacement of Air Balance Honeywell ML & MS with Belimo FSxx Series Actuators

Contents

UL®	2
Code and Standard Issues.....	2
NFPA 80 (Fire) & NFPA 105 (Smoke)	3
Local Code Approval.....	4
Cross Reference	5
Fire & Smoke Damper Technical Details.....	8
Replacement Instructions.....	9
Mounting Methods	10
Linkage mounting.....	14
Miscellaneous parts	15
Thermal sensor replacements – BAE165 US	15
Auxiliary Switches	16
Wiring	17
Building Official/Fire Marshal Notification Form	19

Contacts:

Chris Sheehan 203 749-3112	Larry Felker 775 355-2461 (775 250-4160 Cell)
Mike Knipple 203 749-3170	Laure Pomianowski 775 355-2466
800 543-9038	



WARNING!

**Installer must be trained and experienced with repair
of fire and smoke dampers and actuators.**

UL®

In the “Marking & Application Guide, Dampers for Fire Barrier and Smoke Applications & Ceiling Dampers” April 2013 by Underwriters Laboratories Inc.®, page 6 they state:

DAMPER ACTUATORS

“... field mounting or substitution of actuators is not covered within the scope of the UL certification of the product. However, this does not necessarily preclude replacement of actuators in the field. Like any appliance, field servicing of these products is not covered under the scope of the UL certification and factory follow-up service program. As with any part of the damper, it is expected that replacement of actuators in the field be done in accordance with the damper manufacturer’s normal field servicing program.”

Code and Standard Issues

In general, the administrative section of codes states that all mechanical and electrical systems must be kept in working order and an individual section may state that all life safety devices and systems must be operable. NFPA 80 (Fire) & NFPA 105 (Smoke) require periodic testing and repair of dampers as soon as possible after any deficiency is uncovered. Required testing is shown in the chart below.

Chapter 7 IBC & IFC "Containment" Dampers	
Commissioning End of first year Every 4 years except in hospitals every 6 years	
Chapter 9 IFC "Smoke Control System" Dampers	
Dedicated	Non-dedicated
Commissioning Semi-annually	Commissioning Annually
Chapter 9 IBC & IFC Fire detection & Smoke control systems	
Dedicated	Non-dedicated
Weekly self-test	Not required

Fire & smoke dampers are appliances and field replacement of components is required when failure of any component occurs.

The Authority Having Jurisdiction (local Fire Marshal and/or Building Official) must be consulted if any blade or auxiliary switches are employed and are connected to the fire alarm system or to a Fire Fighters Smoke Control System (FSCS) panel. Retesting is required. A permit and inspection may be required since connections to an alarm system have been touched.

NFPA 80 (Fire) & NFPA 105 (Smoke)

NFPA requires damper inspection and repair of dampers.
See www.nfpa.org for Standards. Details not covered here.

See NFPA 80 & NFPA 105 for details. The damper cleaning and examination check list here is based on them.

Damper installation shall meet code requirements. Fire stopping and drywall integrity shall be confirmed. Damper blades shall be in plane of wall. Duct shall be fall away with no fasteners connected to damper sleeve.

- a. Dampers and ducts shall be cleaned of all foreign debris and dust build-up.
- b. All exposed moving parts of the damper shall be dry lubricated as required by the manufacturer. Do not use oil as it draws dirt.
- c. Damper shall be examined without defective old motor or new actuator to determine:
 - i. The damper shall fully close from the open position.
 - ii. Damper shall fully open from the closed position.
 - iii. There are no obstructions to the operation of the damper. The damper shall not be blocked from closure in any way due to rusted, bent, misaligned, or damaged frame or blades. The damper shall not have defective hinges, side &/or blade seals, or other moving parts. The damper frame shall not be penetrated by any foreign objects that would affect operation.
- d. If the damper is equipped with a fusible link, the link shall be removed for testing to ensure full closure and lock-in-place if so equipped. If the link is damaged or painted, it shall be replaced with a link of the same size, temperature, and load rating.
- e. The fusible link shall be reinstalled after testing is complete.

After installation and wiring of new actuator it shall be tested.

- a. The checklist may be customized using material here and in NFPA Standards. Multiple geometric configurations of springs, fusible link, thermal sensor(s), and actuation are possible. Confirm with AHJ if any additional requirements exist.
- b. Electric thermal sensors, if present, must be tested and replaced if defective.
- c. The test shall be conducted with normal HVAC airflow.
- d. When equipped with smoke detection activation, the smoke detector shall be activated and damper operation observed.

Test voltage input to actuators and repair as necessary if voltage is not correct. Old breakers often deliver below 115V and failed actuators may be due to power supply problems.

A record of all repairs must be kept on site and made available to AHJ.

Local Code Approval

While it is not detailed in codes, the following rules should be followed for selecting Belimo actuators for replacement:

Check the technical specifications to ensure an “equal or better” actuator is used.

- **Temperature** – the replacement actuator shall have been UL555S tested at the same or better temperature as the original actuator. 250°F or 350°F are standard.
- **Time** – the replacement actuator shall drive open and spring closed at a speed equal or faster than presently required by codes. (The AHJ may grant an exception and “grandfather” slower actuators where the original actuator was slower.)
- **Torque** – replacement actuator shall have equal or greater torque than the failed actuator.
- **Voltage** – replacement actuator shall have the same voltage rating as the original.
- **Amperage** – the replacement actuator(s) shall not draw more amperage than the original(s) and cause the total connected amp draw on a circuit breaker to be greater than allowed by electrical code.
- **Final Testing** – actuated damper and associated devices shall be tested for proper operation. See Fire Marshal Notification Form on last page.

(Mnemonic device: TTT-VAT)



WARNING!

In all cases, installation must comply with any and all local electrical and life safety codes. Operation of the system after installation must be performed to verify proper damper cycling. Final checkout requires verifying correct function.

NEGATOR SPRING DAMPERS

Where old negator spring damper motors were replaced by a Honeywell, the spring should have been removed and a new thermal sensor installed. If this has not been done, call Belimo for special instructions.

Some instructions are available at:

<https://www.belimo.us/solutions/actuators/product-documentation/damper-actuators-fire-and-smoke#tab2>



WARNING!

Disconnect and lock out power before starting to disconnect old motor.

Cross Reference

See www.belimo.us/firesmoke or https://www.belimo.us/mam/americas/technical_documents/pdf-web/fire_and_smoke_doc/fire_smoke_competitive_replacement_data_reference.pdf for greater detail.

Honeywell	Voltage	Control	Torque	Aux	Replacement	
ML4105A1000	120 VAC	On/Off	30		FSLF120 US	*
ML4105B1009	120 VAC	On/Off	30		FSLF120 US	*
ML4105C1008	230 VAC	On/Off	30		FSLF230 US	*
ML4105D1007	230 VAC	On/Off	30		FSLF230 US	*
ML4115A1009	120 VAC	On/Off	30		FSLF120 US	*
ML4115A1017	120 VAC	On/Off	30		FSLF120 US	*
ML4115B1008	120 VAC	On/Off	30		FSLF120 US	*
ML4115B1016	120 VAC	On/Off	30		FSLF120 US	*
ML4115C1007	230 VAC	On/Off	30		FSLF230 US	*
ML4115C1015	230 VAC	On/Off	30		FSLF230 US	*
ML4115D1006	230 VAC	On/Off	30		FSLF230 US	*
ML4115D1014	230 VAC	On/Off	30		FSLF230 US	*
ML4115H1002	120 VAC	On/Off	30		FSLF120 US	*
ML4115J1019	120 VAC	On/Off	30		FSLF120 US	*
ML4202F1000	120 VAC	On/Off	20		FSLF120 US	*
ML4202F1000	120VAC	On/Off	20		FSLF120 US	*
ML4302F1008	120 VAC	On/Off	20		FSLF120 US	*
ML8105A1006	24 VAC	On/Off	30		FSLF24 US	*
ML8105B1005	24 VAC	On/Off	30		FSLF24 US	*
ML8115A1005	24 VAC	On/Off	30		FSLF24 US	*
ML8115A1013	24 VAC	On/Off	30		FSLF24 US	*
ML8115B1004	24 VAC	On/Off	30		FSLF24 US	*
ML8115B1012	24 VAC	On/Off	30		FSLF24 US	*
ML8115H	24 VAC	On/Off	30		FSLF24 US	*
ML8115J	24 VAC	On/Off	30		FSLF24 US	*
ML8202	24 VAC	On/Off	20		FSLF24 US	*
ML8302	24 VAC	On/Off	20		FSLF24 US	*
MS4104F1010	120 VAC	On/Off	30		FSLF120 US	*
MS4104F1210	120 VAC	On/Off	30	2	FSLF120-S US	*
MS4109F1010	120 VAC	On/Off	80		FSNF120 US	
MS4109F1210	120 VAC	On/Off	80	2	FSNF120-S	
MS4120F1006	120 VAC	On/Off	175		FSAFA120	
MS4120F1204	120 VAC	On/Off	175	2	FSAF120A-S	
MS4209F1007	120 VAC	On/Off	80		FSNF120 US	
MS4309F1005	120 VAC	On/Off	80		FSNF120 US	

MS4604F1010	230 VAC	On/Off	30		FSLF230	*
MS4604F1210	230 VAC	On/Off	30	2	FSLF230-S	*
MS4609F1010	230 VAC	On/Off	80		FSNF230	
MS4609F1210	230 VAC	On/Off	80	2	FSNF230-S	
MS4620F1005	230 VAC	On/Off	175		FSAF230A	
MS4620F1203	230 VAC	On/Off	175	2	FSAF230A-S	
MS4709F1014	230 VAC	On/Off	80		FSNF230 US	
MS4809F1012	230 VAC	On/Off	80		FSNF230 US	
MS7520A2015	24 VAC	2-10V, 4-20mA	175		FSAFB24-SR US	
MS8104F1010	24 VAC	On/Off	30		FSLF24	*
MS8104F1210	24 VAC	On/Off	30		FSLF24	*
MS8109F1010	24 VAC	On/Off	80		FSNF24	
MS8109F1210	24 VAC	On/Off	80	2	FSNF24-S	
MS8120F1002	24 VAC	On/Off	175		FSAF24A	
MS8120F1200	24 VAC	On/Off	175	2	FSAF24A-S	
MS8209F1003	24 VAC	On/Off	80		FSNF24 US	
MS8309F1001	24 VAC	On/Off	80		FSNF24 US	
S20230-F	230 VAC	On/Off	175		FSAF230A	
S20230-F-SW2	230 VAC	On/Off	175	2	FSAF230A-S	
S2024-F	24 VAC	On/Off	175		FSAF24A	
S2024-F-SW2	24 VAC	On/Off	175	2	FSAF24A-S	
SPH2 Aux Switch						**
32003532-002 Aux Switch						**

* Use FSNF series if damper is > 4 sq.ft.

** Use -S model of proper voltage.

Nominal sq.ft. per UL555S testing.	Temp	Actuator	
<4	350°F	FSLF	36" w x 24" h also.
<12	350°F	FSNF	Multisections also.
<16	250°F	FSNF	Multisections also.
<18	350°F	FSAF*A	Multisections also.

The FSTF series actuators were introduced in 2013. They are 18 in-lb and designed for under 1.5 sq.ft. of fire and smoke damper. Use on larger dampers only when replacing an existing FSTF on a fire and smoke damper.

The FSLF is recommended for small dampers.

Belimo actuators pass UL555S at the same damper sizes as the Honeywell.	NOTE. Although an actuator may operate a larger sized damper use the UL listed sizing. Call for assistance.
---	---

Siebe/Barber Coleman	Power	Torque	Aux Switches	Belimo	Notes
MA220	120 VAC	30		FSLF120 US	1, 2, 4
MA221	240 VAC	30		FSLF230 US	1, 2, 4
MA223	24 VAC	30		FSLF24 US	1, 2, 4
MA230	120 VAC	50		FSNF120 US	1, 2, 3
MA231	240 VAC	50		FSNF230 US	1, 2, 3
MA233	24 VAC	50		FSNF24 US	1, 2, 3
MA240	120 VAC	50			5,6
MA250	120 VAC	50		FSNF120 US	1, 2, 3, 4
MA251	230 VAC	50		FSNF230 US	1, 2, 3, 4
MA253	24 VAC	50		FSNF24 US	1, 2, 3, 4
MA-318	24 VAC	60		FSNF24 US	1, 3
MA-318-500	24 VAC	60	1	FSNF24 -S US	1, 3
MA-418	120 VAC	60		FSNF120 US	1, 3
MA-418-500	120 VAC	60	1	FSNF120-S US	1, 3
1	Direct couple the Belimo where shaft is available. Some were direct coupled.				
2	FSTF <1.5 sq.ft. FSLF <4 sq.ft.				
3	FSNF <12 sq.ft. FSAF*A <18 sq.ft.				
4	For Pottorff with shaft spring see: https://www.belimo.us/mam/americas/technical_documents/pdf-web/fire_and_smoke_doc/pottorff-ma2xx_to_belimo.pdf				
5	Motor was not 90 degree and pulley and cable were usually used. Some geometric changes are necessary to simplify.				
6	Provide photos. Motor, linkage, blades, fusible link, McCabe © Link, Typically direct couple to damper shaft if available. Otherwise, investigation necessary.				

Siemens

Make & Model	Power	Belimo Replacement	
GGD121	24	FSAF24	FSNF24
GGD221	120	FSAF120	FSNF120
GGD321	230	FSAF230	FSNF230

GND12x.1x	24V		FSLF24
GND22x.1x	120V		FSLF120
GND32x.1x	230V		FSLF230

Electronic Fuse Link (24 Vac)

ASK79.165 165°F (74°C)	BAE165 US
ASK79.212 212°F (100°F)	None. Call if needed.
ASK79.250 250°F (121°C)	None. Call if needed.
ASK79.350 350°F (177°C)	None. Call if needed.


Optional	Two Auxiliary Switches Fixed 5° and 85°
----------	---

Fire & Smoke Damper Technical Details

A number of different brackets have been used. All allow mounting of Belimo.



Small bracket




Large bracket




WARNING!

Read Data Sheet provided in box with each actuator for specific wiring details.



For short shaft mounting, the ZG-LMSA-1/2-5 can be used. Alternately, the clamp can be installed between the actuator and sheet metal.



165°F (typical) sensor

Sheet metal holder bracket and mounting plate.

This compartment does not have to be opened except to reset sensor during acceptance testing. The bracket does not have to be removed from damper.

Shown here for instruction.

Four bolts hold actuator to the mounting plate.

Replacement Instructions

1. Disconnect power and wires from motor in wiring compartment.
2. Disconnect flex connection from actuator to mounting base.
3. Loosen set screws on shaft and 4 screws holding motor to base. Remove motor.
4. Several anti-rotation mounting scenarios are possible. See Mounting Methods below.
5. Mount Belimo FSLF or FSNF over shaft.
6. Connect anti-rotation strap.
7. Close damper tightly, tighten nuts on clamp.
8. Pull out old wires and pull Belimo wires thru flex. Cut off excess. Wire nut Belimo wires to existing sensor wires.
9. Connect green ground on 120V models. Connect hot and neutral (or common if 24VAC). See Wiring Methods below.

Conformance test required. See Fire Marshal form on last page.

Mounting Methods




Typical External Mount

Note: short shaft.

Short Shaft Mounting

The Belimo clamp is very stable when mounted between the actuator and the supporting sheet metal.

After mounting, tighten the clamp nuts with a 10mm, long-nosed, deep-well, 1/4" drive socket.




Actuators are mounted on the sleeve of the damper some cases with a remote sensor and sometimes within the sheet metal bracket shown below.

in





Belimo FSLF anti-rotation strap (yellow arrows). Shaft adaptors and other mounting plates are available.



For small dampers where the actuator must hang out in the air.





In all cases, the stud of the anti-rotation strap should fit in the middle of the slot at the bottom of the Belimo. This allows the actuator to move as necessary to compensate for any non-concentric rotation of the damper shaft.



FSTF

Best solution for small dampers where the HW bracket has been hung out into the air is to use an FSTF actuator





WARNING!

Actuator anti-rotation strap may not be screwed to the duct. It must attach to either the sleeve or to the mounting bracket. The duct must be able to fall away from the damper in case of ceiling collapse in a fire.

If replacing a motor used on a damper with fusible link and shaft spring, investigate operation and determine that external spring and link are operable. Refer to damper manufacturer's instructions for the specific damper in question.



WARNING!

USE CAUTION!

Spring is under high torsion and may cause serious injury! If any external springs are present, exercise caution – wear face and hand protection.


Internal Mounted

The Belimo actuator is located in the same place when internally mounted. The jackshaft goes through the Belimo and the anti-rotation strap holds the other end.

If needed, a perforated strap or U shaped sheet metal bracket can be put around the actuator for mechanical support.

The jackshaft is disassembled to remove old motor and mount the Belimo actuator.

Wiring and testing internally mounted actuators is identical to that for the externally mounted actuators.




Linkage mounting

FSLF has no linkage capability




WARNING!

Read Data Sheet provided in box with each actuator for specific wiring details.



Possible alternate arrangements for damper clip. (FSNF, FSAF actuators shown.)



Belimo linkage kits:

https://www.belimo.com/pim/mam/americas/technical_documents/data_sheets/man-air-acc/Mechanical_Accessories.pdf

Mounting Methods Guide:

https://www.belimo.us/mam/americas/technical_documents/pdf-web/guides/mounting_methods.pdf

Miscellaneous parts

Should they be needed, Belimo carries a range of parts. Ball joints and 5/16" rods are available from most distributors.



KH12

Where the crank arm on the jackshaft is broken or not of the type needed, the KH12 fits over the shaft without removing it. Zinc plated steel. Slot is for the KG10A ball joint. V-bolt fits 3/4" to 1" (20 to 25mm) shafts.



KH8

KH-6. Zinc plated steel. For shafts 3/8" to 11/16" Uses KG6 ball joint. Slot width 1/4"

KH-8. Zinc plated steel. For shafts 3/8" to 11/16" Uses KG8 (90 degree) or KG10A ball joint. Slot width 21/64"



KG8 3/8"



KG6, KG10A 1/4"

SH8 (not shown – see picture page 9). Push-rod for KG6 & KG8 ball joints. 5/16" 36" long
Use SH10 3/8" rods for GMB and dual FSAF or FSNF linkages. 5/16" can bend under heavy loads.

ZG-DC1



ZG-DC2

ZG-DC1

Damper blade clip and ball joints for blades typically 3.5" in width. Typically the actuator or rod to shaft is in front of blade.



ZG-DC2

Damper blade clip and ball joints – typically used for 6" wide blade control dampers. Typically the actuator or rod to shaft is above or below the damper.

Thermal sensor replacements – BAE165 US



Belimo BAE165 US

Where existing sensor is defective or one must be added, the 165°F primary sensor may be used.

Original equipment is recommended although not strictly required by code. UL does not regulate replacement or repair. See NFPA 80 or NFPA 105.

Auxiliary Switches

Damper blade switch assembly




Externally mounted auxiliary switches



Where the original switches for signaling position to a Fire Fighters' Smoke Control Panel or to local indicator lights must be replaced or are inoperative the Belimo -S model actuators may be used or a S2A-F may be installed.

Belimo S2A-F

FSLF (mid 2014ff), FSNF, and FSAF actuators can use the add on switch package.




Wiring

There are three wiring schemes that describe all applications. While the geometry of the wire runs may vary, the connections are straightforward.


TYPICAL FIRE - SMOKE COMBINATION DAMPER WIRING

Electric thermal disc



Regardless of the wiring routes used, this drawing shows the wiring necessary for a UL555S damper and actuator. Use it as a basis for any of the other wiring schematics. Note that the alarm connections are not touched when replacing an actuator. This is a major concern for Fire Marshals.


Honeywell with actuator wiring compartment used for junctions.



If necessary add a chase nipple and junction box as shown above right for wiring connections.

The wiring below is commonly connected to alarm or smoke control electronic modules in modern systems. The functional sequence is the same.


TYPICAL REOPENABLE DAMPER with FSCS



In rare cases the Honeywell motor was installed as a retrofit on dampers with fusible links. There is no electric sensor in the damper in that case as there is typically a shaft spring performing the fire function. Wiring is shown to right.

Fusible link DAMPER ACTUATOR WIRING

SMOKE DAMPER ACTUATOR WIRING



Investigate cause of Honeywell failure. For example, was old external spring removed correctly?



WARNING!

Note that where any fire alarm wiring is touched, the fire department must be informed.

Building Official/Fire Marshal Notification Form

Retain this portion of checklist at premises for Fire Marshal inspection. See local AHJ or Fire Marshal for other information and requirements regarding conformance with NFPA 80 & NFPA 105.

☐ Test Checklist (Smoke dampers do not have sensors. Only steps a & b apply.)

1. Single Sensor Combination Damper

- a. ☐ Open smoke detector or relay wire or contact to cut power. *Damper springs closed.*
- b. ☐ Reconnect power. *Damper drives open.*
- c. ☐ Open thermal sensor using heat gun. *Damper springs closed.*
- d. ☐ Press thermal sensor manual reset. *Damper drives open.*

Repeat 3 times to ensure operation. This imitates UL555S test.

2. Reopenable Two Sensor Fire-Smoke Combination Damper

(Since this system involves the Firefighters' Smoke Control System, inform fire department.)

With FSCS switch in Auto position:

- a. ☐ Disconnect power from smoke detector or relay contacts. *Actuator springs damper closed.*
- b. ☐ Reconnect power. *Actuator drives damper open.*
- c. ☐ Trip thermal sensor. *Actuator springs damper fully closed.*
- d. ☐ Press manual reset. *Actuator drives damper open.*

Test FSCS switch functions:

- a. ☐ Move FSCS switch to Off position. *Actuator springs damper fully closed.*
- b. ☐ Move FSCS switch to Hand position. *Actuator drives damper open.*
- c. ☐ Trip secondary (higher temperature) thermal sensor. *Actuator springs damper fully closed.*
- d. ☐ Press manual reset of secondary sensor. *Actuator drives damper open.*

Move FSCS switch back to Auto position:

- a. ☐ Actuator springs damper closed if Primary sensor is still open.
- b. ☐ Actuator stays open if Primary sensor has re-closed.

☐ When completed, ensure sensors are reset and smoke detector is in normal state and FSCS switch is in Auto. Damper is normally Open; check sequence of operation.

Damper Numbers or Location Identifying Numbers.....

Date.....-.....-.....

Contractor.....

Service Technician (Print).....

Service Technician (Signed).....

Phone Number (.....).....

Notes.....

.....

.....